



FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6

28

55

62

60

60

63

REGISTRATION

NAME

ADDRESS

CREDIT CARD

NAME OF CHILD

EYES

FAVORITE COLOR

FAVORITE CARTOON

FAVORITE T.V. SHOW

DONE

The diagram shows a registration form on a device screen. The form is titled "REGISTRATION" and contains several input fields. The fields are: NAME, ADDRESS, CREDIT CARD, NAME OF CHILD, EYES, FAVORITE COLOR, FAVORITE CARTOON, FAVORITE T.V. SHOW, and a DONE button. A dashed line separates the top three fields from the bottom six. Arrows point from labels 28, 55, 62, 60, 60, and 63 to various parts of the form and the device frame.

FIG. 7




FIG. 8

